

Mini Bank 1500 Operator Manual



Nautilus
HYOSUNG

Copyright Nautilus Hyosung Inc. 2004 All right reserved

Revision Record

Date	Page	Version	Description of Change
April 2004	All	1.0	New Publication
July 2004	Partial	1.1	Adding the UK Version (Optional)
January 2005	Partial	1.2	Adding error codes for CDU and SPR

Table of Contents

1. Introduction	
1.1 About Mini Bank 1500	1-2
1.2 Features	1-2
1.3 What is in this Manual	1-3
2. Safety Precautions	
2.1 Overview	2-2
2.2 Description of Precaution Symbols	2-3
3. Hardware Specifications	
3.1 Dimension	3-2
3.2 Component Locations	3-3
3.3 LCD & Customer Keypad	3-4
3.4 Cash Dispenser Unit	3-5
3.5 Receipt Printer	3-6
3.6 Main Control Board	3-7
3.7 Operating Environment	3-8
3.8 Optional Devices	3-9
4. Installation	
4.1 Unpacking	4-2
4.2 Physical Installation	4-3
4.3 Hardware Installation	4-5
5. Operating Instructions	
5.1 Opening and Closing the Security Door	5-2
5.2 Opening and Closing the Front Panel	5-4
5.3 Replenishing the Cash Cassette	5-6
5.4 Emptying the Reject Bin	5-9
5.5 Loading the Receipt Paper	5-10
5.6 Additional Instructions (Option)	5-12

6. Operator Functions

6.1 Basic System Operation	6-2
6.2 Settlement	6-6
6.3 Journal	6-14
6.4 Report	6-26
6.5 Diagnostics	6-35
6.6 Customer Setup	6-46
6.7 System Setup	6-60
6.8 Host Setup	6-78
6.9 Transaction Setup	6-106

7. Appendix

A. Receipt Paper Specifications	7-2
B. Note Conditions (Acceptable/Unacceptable)	7-3
C. Operating and Changing the Electronic Combination Lock	7-6
D. Error Codes	7-8
E. How to Clear NV-RAM	7-11
F. Pictures of Mini Bank 1500	7-13