

IBM
Wincor Nixdorf Procash 1100(6810)
Configuration Guide
For AT-Link Software on Windows NT
Version 2.6.0.1
Direct Cash

Purpose:

The purpose of this document is to provide the procedure for the configuration of the ProCash 1100 ATM that is using AutoTell, AT-Link/NT software. In this document will cover software installation and configuration procedures.

Items Required:

- 1) You will require Canadian sized test documents or real money to complete this configuration. You will need enough for all cassettes being configured with the software.
- 2) Access to the safe. This is required to allow access to the cash cassettes.
- 3) You will require a PC keyboard with a PS/2 sized connector.
- 4) 1 blank diskette
- 5) The machine configuration usually available in the machine, the customer help desk also maintains all this (serial number, terminal ID, license, etc.)

Reconfiguration process

In case you entered wrong information during the configuration after you have loaded or recovered software, there is a way to reinitiate the configuration process. You can also use this process to simply reconfigure an ABM that need to be redeployed

1. Press CTRL-ALT-DELETE
2. Select Task Manager
3. Select New Task
4. Using the cursor key find C:\winnt\explorer.exe, and press enter
5. Go to the C:\utils directory
6. Find the file config.bat, select it and press enter
7. Answer the question on the screen
8. Press the reboot button on the Special electronic
9. Follow the configuration procedure

***** Note, if you initiate the reconfiguration process, always reenter the terminal ID, even if it tell you that it found one already. *****

Software Configuration for Asynchronous (Dialing a host phone number) based machines

This section covers the software configuration for Asynchronous based machines. Follow all the steps in this section if you had to change the hard drive or reloaded the software for some reason.

The ATM will boot up and show a blue screen that asks for about the encryption module.

Note: The following section is based on what you will see on the ATM's screen. Text using Courier type is what is displayed. Types in Times Roman Bold are notes about that screen. *** indicates a screen change.

```
Does this machine has an encryption/decryption
Hardware module (EDM) or an encrypting pin pad
(EPP)? If you select "Neither", software
Encryption will be used.
1) EDM
2) EPP
3) Neither
```

Select 2 for EPP

```
Does this machine have soft keys or a touch screen?
1) Softkeys
2) Touch
```

Select 1 for Softkeys

```
This machine has been reconfigured to use an EPP with/without
Softkeys
Hit any keys to continue.
```

Hit any key, this is a confirmation screen only

Enter Terminal ID: _____
(8 digit number for DirectCash ABM)

***** STOP! and confirm this number before pressing the ENTER key ******

This product requires a license for activation. To obtain your License activation key, please contact AutoTell Systems, Inc. By phone: 1-888-SNI-ATMS. Please have the following machine Identifier ready: xx-xxxxx

Enter the License key, then hit ENTER

License Activation Key: xxxx-xxxxx-xxxx

(Enter the license key for async communication; DO NOT CALL AUTOTELL, IBM RESPONSIBLE TO PROVIDE THE KEYS FOR CANADIAN CUSTOMER)

Select Transaction processor

- 1) EPS
- 2) USPI
- 3) ATMI
- 4) CoreData
- 5) Commlink
- 6) Genpass
- 7) TCS (Canada)
- 8) CGI (Canada)
- 9) Threshold (Canada)
- ... More Choices

Select 7, it will get modified automatically for the Direct Cash switch

In order to initialize the cassettes, at least 50 bills will be necessary to load into each cassette. Press any key to Continue

Enter number of cassettes
Not including the reject Cassette ____
(Count number of feed channels in the ATM. A cash cassette with money will be required for each module configured!!)

Select Denomination for cassette 1
Selection: ____
(Enter the denomination you wish to use for this cassette)

Select Denomination for cassette 2
Selection: ____
(Enter the denomination you wish to use for this cassette)

Select Denomination for cassette 3
Selection: ____
(If installed, enter the denomination you wish to use for this cassette)

Select Denomination for cassette 4
Selection: ____
(If installed, enter the denomination you wish to use for this cassette)

Enter Number of Bills in Cassette 1 ____
(200, or other count)

Enter Number of Bills in Cassette 2 ____
(200, or other count)

Enter Number of Bills in Cassette 3 ____
(200, or other count, if installed)

Enter Number of Bills in Cassette 4 ____
(200, or other count, if installed)

Remove ALL cassettes including the Reject
Cassette and then hit the ENTER key

Load money into cassettes then hit ENTER key
**(Install at least 1/2" of Canadian sized test
documents, or real money in each cash cassette.)**

Replace ALL cassettes then hit the ENTER key

Pull out the Reject Cassette then hit the ENTER key

Remove any, and all, bills from the Reject Cassette
then hit the ENTER key

Push in the Reject Cassette then hit the ENTER key

Reference Check on cassette 1

Pull out the Reject Cassette then hit the ENTER key

Remove the bills from the Reject Cassette, count the bills,
And do NOT place the bills back in the Reject Cassette.
If you counted X bills then hit the ENTER key
Otherwise hit CANCEL

Push in the Reject Cassette then hit the ENTER key

Reference Check on cassette 2

Pull out the Reject Cassette then hit the ENTER key

Remove the bills from the Reject Cassette, count the bills,
And do NOT place the bills back in the Reject Cassette.
If you counted X bills then hit the ENTER key
Otherwise hit CANCEL

Push in the Reject Cassette then hit the ENTER key

Reference Check on cassette 3

Pull out the Reject Cassette then hit the ENTER key

Remove the bills from the Reject Cassette, count the bills,
And do NOT place the bills back in the Reject Cassette.
If you counted X bills then hit the ENTER key
Otherwise hit CANCEL

Push in the Reject Cassette then hit the ENTER key

Reference Check on cassette 4

Cash Initialization Complete

Load Key

Enter 1st Part of Master key

> _____ <
> _____ <

(Enter all 1's , or the real encryption key if you have it already)

Load Key

Enter 2nd Part of Master key

> _____ <
> _____ <

(Enter all 1's , or the real encryption key if you have it already)

Key Check

Verification Code: XXXX

Hit Enter to accept, or any
other key to try again

(Hit Enter)

Encryption keys loaded

Enter the ATM Identification, which is the last 8 digits
of the Serial Number on the silver sticker on the safe door

Enter ATM Identifier: _____

(Type the last 8 digit of the ATM serial number, if you look at the blue sticker, please append a 0 in front)

Select Primary Phone Number

1) 1-888-827-4811

2) Other _

(Enter option 2 to configure to your switch phone number)

Enter Primary Phone Number (digits only)
Then hit the ENTER key

(Enter the switch primary phone number)

Select Secondary Phone Number

1) 1-888-827-4811

2) Other _

(Enter option 2 to configure to your switch phone number)

Enter Secondary Phone Number (digits only)
Then hit the ENTER key

(Enter the switch secondary phone number)

Select type of Modem being used

1) Practical Peripheral

2) US Robotics

3) Zoom

Selection ____

(select 3, Zoom)

Enter Time and Date in 24 hour format

Current Time: hh:mm
Current Date: mm/dd/yyyy

F10 to save changes or ESCAPE to abort

(Correct time if needed and press F10)

The Windows NT Date/Time configuration window will now
Appear for you to configure your date, time, and time zone.

Hit any key to continue.

**(you can now select the correct time zone and DST... When the Window screen show up. Use the
cursor key to select, enter to confirm)**

Customer Receipt Header Text English

(Leave blank, or type the text you wish to use)

F10 to save changes or ESCAPE to abort

Customer Receipt Header Text French

(Leave blank, or type the text you wish to use)

F10 to save changes or ESCAPE to abort

Customer Receipt Footer Text English

(Enter the text you wish to use)

F10 to save changes or ESCAPE to abort

Customer Receipt Footer Text French

(Enter the text you wish to use)

F10 to save changes or ESCAPE to abort

Enter surcharge amount for this machine
Then hit the ENTER key

(Format = #.##)

Configuration Complete
(Note still more questions)

Does this ATM have a back panel SOP?
If you are unsure select NO

- 1) Yes
- 2) No

Selection ____

(Select 2, NO)

Back Panel SOP Complete

Do you have any update diskettes/CD

- 1) Yes
- 2) No

(Select 2, unless you have update disks)

Update complete

Do you have any Customization diskettes/CD

- 1) Yes
- 2) No

(Select 2, unless you have customization disks)

Customization complete
